

C/05

A BN

Switch - disconnectors



ROVE Electric Pvt Ltd.

ABN offers wide range of switch disconnectors for manual operation. The range of switch disconnectors confirms to latest IEC 60947-3 standards. The products are in line with best design and quality standards.




Features and benefits

- CB certifications for IEC 60947-3 from UL lab to conform IEC 60947-3/EN 60947-3/UL 60947-3/IS: 13947-3
- Compact and modular construction
- AC-23A rating for voltage level up to 690/1000V
- Double quick make / break operation feature that enhance performance
- Clear on / off indication in front of the switch by providing a lense
- Provision for add on auxiliary contact for identification of switch position
- Front operated mechanism
- Suitable for vertical, horizontal, upwards, downwards orientation
- Modular switch, can be configured from single pole to 8 pole


ABN switch disconnectors were developed according to IEC 60947-3 and enable the manual drive of motors, machines and other equipment. Besides carrying and interrupting electric currents under normal or over load conditions, the design of the switches provides complete physical insulation between the circuit on the power supply when in the Off position. In this position, it is possible to use 3 pad locks in order to prevent inadvertent actuations, increasing the safety of operators and maintenance personnel

ABN switch disconnectors provide reliable production for personnel and ensure high system availability- in buildings, infrastructure and industrial plants. With these switches you can implement your protects more efficiently and thus safe guard your competitiveness

Products are conforms to CE RoHS

**20...125A****125...250A****315...500A****IEC**

| | | | |
|--------------------------------|---|--------------------|---------------|
| I_{th} in A | 20, 25, 32, 40, 50, 63, 80, 100, 125 | 125, 160, 200, 250 | 315, 400, 500 |
| $I_{e AC}$ 22A / AC23A in A | 20, 25, 32, 40, 50, 63, 80, 100, 125 | 125, 160, 200, 250 | 315, 400, 500 |

**500...800A****1000...1600A****2000...3200A****IEC**

| | | | |
|--------------------------------|---------------|------------------|------------------|
| I_{th} in A | 500, 630, 800 | 1000, 1250, 1600 | 2000, 2500, 3200 |
| $I_{e AC}$ 22A / AC23A in A | 500, 630, 800 | 1000, 1250, 1600 | 1600, 2000, 2200 |

Technical Data for Switch - disconnectors

RVSD20...RVSD125 A

| | Rating | A |
|--|--|---|
| Technical data according to IEC 60947-3 | | Switch type |
| Rated insulation Voltage and rated Operational Voltage AC20/DC20 | | V |
| Dielectric Strength | Pollution degree 3 | KV |
| Rated impulse Withstand Voltage | | KV |
| Rated thermal current and rated operational current AC20/DC20 | Ambient 40°C Ambient 40°C Ambient 60°C | In open air In enclosure In enclosure Cu |
| With minimum conductor cross section | | A A A mm ² |
| Rated operational current, AC-21A | Up to 415 V 440...690 V | A A |
| Rated operational current, AC-22A | Up to 415 V 440...500 V 690 V | A A A |
| Rated operational current, AC-23A | Up to 415 V 440 V 500 V 690 V | A A A A |
| Rated operational current / poles in series,DC-21A | 24...48 V 110 V 220 V 440 V 500 V | A A A A A |
| Rated operational current / poles in series,DC-22A | 24...48 V 110 V 220 V 440 V | A A A A |
| Rated operational current / poles in series,DC-23A | 24...48 V 110 V 220 V 440 V | A A A A |
| Rated operational power, AC-23A (These values are given for guidance and may vary acc. to the motor manufacturer) | 220...240 V 400...415 V 440 V 500 V 690V | kw kw kw kw kw |
| Rated breaking capacity, AC-23A | Up to 415 V 440 V 500 V 690 V | A A A A |
| Rated breaking capacity / poles in series, DC-23A | 24...48 V 220 V 110 V 440 V | A A A A |
| Rated conditional short-circuit current I_p (r.m.s.) and corresponding max. allowed cut-off current I_c . | I_p (r.m.s.) max. fuse size gG/aM | 50 kA ≤ 415 V A |
| The cut-off current I_c refers to values listed by fuse manufacturers (single phase test acc. to IEC60269) | I_p (r.m.s.) max. fuse size gG/aM | 100 kA ≤ 500 V A |
| | I_p (r.m.s.) max. fuse size gG/aM | 10 kA ≤ 690 V A |
| | I_p (r.m.s.) max. fuse size gG/aM | 50 kA ≤ 690 V A |
| Rated short -time withstand current | r.m.s. -value I_{cw} r.m.s. -value I_{cw} | 690 V, 0.25 s 690 V, 1 s kA kA |
| Rated short circuit making capacity | Peak value I_{cm} | 690 V/500 V kA |
| Rated capacity power (the capacitor rating are limited by the fuse link.) | | 400...415 V kVar |
| Power loss / pole | At rated operational current | W |
| Mechanical endurance | Divide by two operation cycles | oper. |
| Weight without accessories | 3-pole 4-pole | Kg Kg |
| Cable size | Cu-wire size suitable for terminal clamps | mm ² AWG |
| Terminal tightening torque | Counter torque required | Nm |
| Operating torque | 3-pole switch-disconnector | Nm |

| 20 | 25 | 32 | 40 | 50 | 63 | 80 | 100 | 125 |
|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|--------------------------------------|---|---|
| RVSD20 | RVSD25 | RVSD32 | RVSD40 | RVSD50 | RVSD63 | RVSD80 | RVSD100 | RVSD125 |
| 750 6 8 | 750 6 8 |
| 32 32 20 4 | 32 32 25 6 | 40 40 32 10 | 40 40 32 10 | 50 50 40 10 | 63 63 50 16 | 80 80 80 80 | 115 115 80 35 | 125 125 100 50 |
| 20 20 | 25 25 | 32 32 | 40 40 | 50 50 | 63 63 | 80 80 | 100 100 | 125 125 |
| 20 20 20 | 25 25 25 | 32 32 32 | 40 40 40 | 50 50 50 | 63 63 63 | 80 80 80 | 100 100 100 | 125 125 125 |
| 20 20 20 12 | 25 25 25 13 | 32 32 32 16 | 40 40 40 20 | 50 50 50 25 | 63 63 63 32 | 80 80 80 40 | 100 100 100 50 | 125 125 125 50 |
| 20/1 20/2 20/3 16/4 16/4 | 25/1 25/2 25/3 16/4 16/4 | 32/1 32/2 32/3 16/4 16/4 | 40/1 40/2 40/3 16/4 16/4 | 50/1 50/2 50/3 16/4 16/4 | 63/1 63/2 63/4 16/4 16/4 | 80/1 80/2 80/4 16/4 16/4 | 100/1 100/2 100/4 16/4 16/4 | 125/1 125/2 125/4 16/4 16/4 |
| 20/1 20/2 20/3 20/4 | 25/1 25/2 25/3 25/4 | 32/1 32/2 32/4 32/4 | 40/1 40/2 40/4 40/4 | 50/1 50/2 50/4 50/4 | 63/1 63/2 63/4 63/4 | 80/1 80/2 80/4 80/4 | 100/1 100/2 100/4 10/4 | 125/1 125/2 125/4 10/4 |
| 20/1 20/2 20/4 10/4 | 25/1 25/2 25/4 10/4 | 32/1 32/2 32/4 10/4 | 40/1 40/2 32/4 10/4 | 50/1 50/2 40/4 10/4 | 63/1 63/2 50/4 10/4 | 80/1 80/2 63/4 10/4 | 100/1 100/2 80/4 10/4 | 125/1 125/2 80/4 10/4 |
| 4 9 9 9 9 | 4 9 9 9 9 | 5 10 10 10 10 | 5.5 11 11 11 11 | 7.5 15 15 15 15 | 11 22 22 22 22 | 22 37 37 37 37 | 22 37 37 37 37 | 22 45 45 45 45 |
| 160 160 160 140 | 200 200 200 175 | 256 256 256 224 | 320 320 320 280 | 400 400 400 350 | 504 504 504 441 | 640 640 640 560 | 800 800 800 700 | 1000 1000 1000 875 |
| 80/1 80/2 80/4 32/4 | 100/1 100/2 100/4 40/4 | 110/1 110/2 110/4 40/4 | 128/1 128/2 128/4 40/4 | 128/1 128/2 128/4 50/4 | 180/1 180/2 180/4 40/4 | 252/1 252/2 180/4 40/4 | 400/1 400/2 252/4 60/4 | 500/1 500/2 252/4 60/4 |
| 6.5 40/32 | 6.5 40/32 | 6.5 40/32 | 6.5 40/32 | 6.5 100/80 | 13 100/80 | 13 100/80 | 16.5 125/125 | 16.5 125/125 |
| | | | | | 17 100/80 | 17 100/80 | 8.2 125/100 | 8.2 125/100 |
| 7 25/16 | 7 25/16 | 7 25/16 | 7 25/16 | 12 100/80 | 12 80/63 | 15 80/63 | 15 80/63 | 18 80/63 |
| 0.5 | 0.5 | 0.5 | 0.5 | 0.5 | 1 | 1.5 | 2.5 | 2.5 |
| 0.705 | 0.705 | 0.705 | 0.705 | 0.705 | 1.4 | 2.1 | 3.6 | 3.6 |
| 10 | 10 | 15 | 15 | 15 | 25 | 30 | 40 | 50 |
| 0.6 20 000 | 0.6 20 000 | 1.6 20 000 | 1.6 20 000 | 1.6 20 000 | 2.8 20 000 | 4.5 20 000 | 4.0 20 000 | 6.3 20 000 |
| 0.4 0.54 | 0.4 0.54 |
| 0.75...10 18-8 | 0.75...10 18-8 | 0.75...10 18-8 | 0.75...10 18-8 | 0.75...10 18-8 | 1.5...35 14-4 | 1.5...35 14-4 | 10...70 8-00 | 10...70 8-00 |
| 1.2 2 | 1.2 2 | 2.2 2 | 2.2 2 | 4 2 | 4 2 | 4 2 | 4 2 | 4 2 |

Ordering information & Mounting dimension


Front operated switch-disconnectors

RVSD20...RVSD125A

Switch-disconnectors, base and DIN-rail mounting, IEC



including protected terminal clamps IP20

The type and the ordering numbers are for one piece.





| No. of poles | I_{th} (open) [A] | Cable cross section [mm ²] | Rated operat. currents AC22A/ AC23A 400 v [A/A] | Type | Order No | Delivery batch [pcs] | Weight/ unit [Kg] |
|--------------------|---------------------------|---|---|-----------|----------------|----------------------------|-------------------------|
| 3 | 20 | 0.75...10 | 20/20 | RVSD2003 | RVESD0020M03H3 | 10 | 0.5 |
| 4 | 20 | 0.75...10 | 20/20 | RVSD2004 | RVESD0020M04H3 | 10 | 0.64 |
| 3 | 25 | 0.75...10 | 25/25 | RVSD2503 | RVESD0025M03H3 | 10 | 0.5 |
| 4 | 25 | 0.75...10 | 25/25 | RVSD2504 | RVESD0025M04H3 | 10 | 0.64 |
| 3 | 32 | 0.75...10 | 32/32 | RVSD3203 | RVESD0032M03H3 | 10 | 0.5 |
| 4 | 32 | 0.75...10 | 32/32 | RVSD3204 | RVESD0032M04H3 | 10 | 0.64 |
| 3 | 40 | 0.75...10 | 40/40 | RVSD4003 | RVESD0040M03H3 | 10 | 0.5 |
| 4 | 40 | 0.75...10 | 40/40 | RVSD4004 | RVESD0040M04H3 | 10 | 0.64 |
| 3 | 50 | 1.5...35 | 50/50 | RVSD5003 | RVESD0050M03H3 | 10 | 0.5 |
| 4 | 50 | 1.5...35 | 50/50 | RVSD5004 | RVESD0050M04H3 | 10 | 0.64 |
| 3 | 63 | 1.5...35 | 63/63 | RVSD6303 | RVESD0063M03H3 | 10 | 0.5 |
| 4 | 63 | 1.5...35 | 63/63 | RVSD6304 | RVESD0063M04H3 | 10 | 0.64 |
| 3 | 80 | 1.5...35 | 80/80 | RVSD8003 | RVESD0080M03H3 | 10 | 0.5 |
| 4 | 80 | 10...70 | 80/80 | RVSD8004 | RVESD0080M04H3 | 10 | 0.64 |
| 3 | 100 | 10...70 | 100/100 | RVSD12503 | RVESD0100M03H3 | 10 | 0.5 |
| 4 | 100 | 10...70 | 100/100 | RVSD12504 | RVESD0100M04H3 | 10 | 0.64 |
| 3 | 125 | 10...70 | 125/125 | RVSD12503 | RVESD0125M03H3 | 10 | 0.5 |
| 4 | 125 | 10...70 | 125/125 | RVSD12504 | RVESD0125M04H3 | 10 | 0.64 |

Shafts and handles included as standard



Placing options of the operating mechanism for RVSD125...250

At the end of
the switch
03 or 04Between
the poles
12 or 22

| | RATING | A | 125 | 160 | 200 | 250 |
|---|--|---|--------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Technical data according to IEC 60947-3 | Switch type | | RVSD125 | RVSD160 | RVSD200 | RVSD250 |
| Rated insulation voltage and rated operational voltage AC-20, DC-20 | Pollution degree 3 | 50 Hz 1min. | V kv kv | 1000 10 12 | 1000 10 12 | 1000 10 12 |
| Dielectric strength | | | | | | |
| Rated impulse voltage | | | | | | |
| Rated thermal current and rated operational current AC-20, DC-20 in ambient 40°C ⁴⁾ with minimum cable cross section | Ambient 40°C Ambient 40°C Ambient 60°C | In open air In enclosure In enclosure Cu | A A A mm ² | 200 125 125 50 | 200 160 160 70 | 200 200 200 95 |
| Rated operational current AC-21A | | ≤ 500V 690V 1000V | A | 125 125 125 | 200 160 160 | 200 200 200 |
| Rated operational current AC-22A | | ≤ 500V 690V 1000V | A | 125 125 125 | 200 160 160 | 250 250 250 |
| Rated operational current AC-23A | | ≤ 500V 690V 1000V | A | 125 125 125 | 160 160 135 | 200 200 135 |
| Rated operational current/ poles in series, DC-21A ¹⁾ | | 24...110 V 220 V 440 V 660 V | A | 125/2 125/2 125/3 125/4 | 160/2 160/2 160/3 160/4 | 200/2 200/2 200/3 200/4 |
| Rated operational current/ poles in series, DC-21B | | 800 V 1000 V | A | 125/5 125/6 | 160/5 160/6 | 200/5 200/6 |
| Rated operational power, AC-23 ³⁾ | | 230 V 400 V 415 V 500 V 690 V | KW KW KW KW KW | 37 64 68 87 112 | 48 80 88 112 144 | 60 110 110 132 200 |
| Rated breaking capacity in category AC-23 | | ≤ 500 V 690 V | A | 1000 1000 | 1280 1280 | 1600 1600 |
| Rated conditional short-circuit I_p (r.m.s.) and corresponding max. allowed cut-off current \dot{I}_c . | I_p (r.m.s.) Max. fuse size | 100 KA,500 V gG/aM | KA A | 40.5 315/315 | 40.5 315/315 | 40.5 315/315 |
| The cut-off current \dot{I} refers to values listed by fuse manufacturers (Single phase test acc.to IEC60269). | I_p (r.m.s.) Max. fuse size | 80 KA,690 V gG/aM | KA A | 40.5 355/315 | 40.5 355/315 | 40.5 355/315 |
| Rated short-time making withstand current | r.m.s I_{cw} | ≤1000 V 0.15s ≤1000 V 0.25s ≤1000 V 1s | KA KA KA | 15 15 8 | 15 15 8 | 15 15 8 |
| Rated short-time making capacity | Peak Value I_{cm} | ≤1000 V 1s | KA | 30 | 30 | 30 |
| Rated capacitor power when no initial charge on the capacitor | The capacitor rating are limited by the fuse link | 415 V 500 V 690 V | KVAr KVAr KVAr | 62 75 100 | 80 96 128 | 100 120 160 |
| Power loss / pole | With rated current | | W | 3.2 | 3.2 | 4 |
| Mechanical endurance | Divide by two oper. cycles | | Oper. | 20 000 | 20 000 | 20 000 |
| Weight without accessories | 3-pole switch | | Kg | 1.95 | 1.34 | 1.34 |
| Terminal bolt size Terminal tightening torque Operating torque | Metric thread diameter x length Counter torque required 3-pole switch disconnector | | mm Nm Nm | M8x25 15-22 7 | M8x25 15-22 7 | M8x25 15-22 7 |

1) Further rating on request

2) Category B

3) These values are given for guidance and may vary acc. to the motor manufacturer

4) Acc. to IEC 60947-1,\$ 6.1.1

Ordering information & Mounting dimension

Front operated switch-disconnectors RVSD125...RVSD250A


Switch-disconnectors, with pistol handle, base mounting, IEC

including a black ON-OFF plastic handle and shaft as standard, The handle is IP65 protected, padlockable in the OFF- position and with door interlock in the ON-position. The shaft can be adjusted to different installation depths.





| No. of poles | I_{th} (open) [A] | I_{th} (closed) [A/A] | Rated operat. currents AC22A/ AC23A 400 V | Type | Order number | Units/ type [pcs] | Weight/ unit [Kg] |
|--------------------|---------------------------|-------------------------------|--|----------------|--------------|-------------------------|-------------------------|
| | | | | | | | |
| 3 | 200 | 200/125 | RVSD12503 | RVESD0125M03H3 | 1 | 1.82 | |
| 4 | 200 | 200/125 | RVSD12504 | RVESD0125M04H3 | 1 | 2.1 | |
| 3 | 200 | 200/125 | RVSD12512 | RVESD0125M12H3 | 1 | 1.82 | |
| 4 | 200 | 200/125 | RVSD12522 | RVESD0125M22H3 | 1 | 2.1 | |
| 3 | 200 | 200/160 | RVSD16003 | RVESD0160M03H3 | 1 | 1.82 | |
| 4 | 200 | 200/160 | RVSD16004 | RVESD0160M04H3 | 1 | 2.1 | |
| 3 | 200 | 200/160 | RVSD16012 | RVESD0160M12H3 | 1 | 1.82 | |
| 4 | 200 | 200/160 | RVSD16022 | RVESD0160M22H3 | 1 | 2.1 | |
| 3 | 200 | 200/200 | RVSD20003 | RVESD0200M03H3 | 1 | 1.82 | |
| 4 | 200 | 200/200 | RVSD20004 | RVESD0200M04H3 | 1 | 2.1 | |
| 3 | 200 | 200/200 | RVSD20012 | RVESD0200M12H3 | 1 | 1.82 | |
| 4 | 200 | 200/200 | RVSD20022 | RVESD0200M22H3 | 1 | 2.1 | |
| 3 | 250 | 250/250 | RVSD25003 | RVESD0250M03H3 | 1 | 1.82 | |
| 4 | 250 | 250/250 | RVSD25004 | RVESD0250M04H3 | 1 | 2.1 | |
| 3 | 250 | 250/250 | RVSD25012 | RVESD0250M12H3 | 1 | 1.82 | |
| 4 | 250 | 250/250 | RVSD25022 | RVESD0250M22H3 | 1 | 2.1 | |

Shafts and handles included as standard



| (mm) | P01 | P02 | P03 | P04 |
|------|-----|-----|-----|-----|
| A | 77 | 110 | 145 | 180 |
| A1 | 55 | 90 | 125 | 160 |
| B1 | 71 | 106 | 141 | 176 |
| C1 | 85 | 120 | 155 | 190 |

Placing options of the operating mechanism for RVSD315...500At the end of
the switch
03 or 04Between
the poles
12 or 22

| Technical data according to IEC 60947-3 | RATING | A | 315 | 400 | 500 | |
|---|--|--|----------------|--|--|--|
| | | | Switch type | RVSD315 | RVSD400 | RVSD500 |
| Rated insulation voltage and rated operational voltage AC-20, DC-20 | Pollution degree 3 | 50 Hz 1min. | V | 1000 | 1000 | 1000 |
| Dielectric strength | | | kv | 10 | 10 | 10 |
| Rated impulse voltage | | | kv | 12 | 12 | 12 |
| Rated thermal current and rated operational current AC-20, DC-20 in ambient 40°C ⁴⁾ with minimum cable cross section | Ambient 40°C Ambient 40°C Ambient 60°C | In open air In enclosure Cu | A A mm² | 315 315 315 185 | 400 400 400 240 | 500 500 500 2x150 |
| Rated operational current AC-21A | | < 500V 690V 1000V | A | 315 315 315 | 400 400 400 | 500 500 500 |
| Rated operational current AC-22A | | < 500V 690V 1000V | A | 315 315 315 | 400 400 400 | 500 500 500 |
| Rated operational current AC-23A | | < 500V 690V 1000V | A | 315 315 200 | 400 400 200 | 500 500 200 |
| Rated operational current / poles in series, DC-21A ¹⁾ | 24...110 V 220 V 440 V 660 V | | A | 315/1 ²⁾ 315/2 ²⁾ 315/3 315/4 | 400/1 ²⁾ 400/2 ²⁾ 360/3 360/4 | 500/1 ²⁾ 500/2 ²⁾ 360/3 360/4 |
| Rated operational current / poles in series, DC-21B | 800 V 1000 V | | A | 315/5 315/6 | 400/5 400/6 | 500/5 500/6 |
| Rated operational power, AC-23 ³⁾ | 230 V 400 V 415 V 500 V 690 V | KW | | 100 160 180 220 315 | 132 220 230 280 400 | 165 275 287 287 500 |
| Rated breaking capacity in category AC-23 | | ≤ 500 V 690 V | A | 2520 2520 | 3200 3200 | 3200 3200 |
| Rated conditional short-circuit I_p (r.m.s.) and corresponding max. allowed cut-off current \hat{I}_c . | I_p (r.m.s.) Max. fuse size | 100 KA,500 V gG/aM | KA A | 61.5 500/450 | 61.5 500/450 | 61.5 500/450 |
| The cut-off current \hat{I} refers to values listed by fuse manufacturers (Single phase test acc.to IEC60269). | I_p (r.m.s.) Max. fuse size | 80 KA,690 V gG/aM | KA A | 59 500/500 | 59 500/500 | 59 500/500 |
| Rated short-time making withstand current | r.m.s I_{cw} | ≤1000 V 0.15s ≤1000 V 0.25s ≤1000 V 1s | KA KA KA | 31 24 15 | 31 24 15 | 31 24 15 |
| Rated short-time making capacity | Peak Value I_{cm} | ≤1000 V 1s | KA | 65 | 65 | 65 |
| Rated capacitor power when no initial charge on the capacitor | The capacitor rating are limited by the fuse link | 415 V 500 V 690 V | KVar | 145 175 250 | 180 215 325 | 225 268 406 |
| Power loss / pole | With rated current | | W | 6.5 | 10 | 15 |
| Mechanical endurance | Divide by two oper. cycles | | Oper. | 16000 | 16000 | 16000 |
| Weight without accessories | 3-pole switch | | Kg | 2.64 | 2.64 | 2.64 |
| Terminal bolt size Terminal tightening torque Operating torque | Metric thread diameter x length Counter torque required 3-pole switch disconnector | mm Nm Nm | | M10x30 30-44 16 | M10x30 30-44 16 | M10x30 30-44 16 |

1) Further rating on request

2) Category B

3) These values are given for guidance and may vary acc. to the motor manufacturer

4) Acc. to IEC 60947-1,\$ 6.1.1


Switch-disconnectors, with pistol handle, base mounting, IEC

including a black ON-OFF plastic handle and shaft as standard, The handle is IP65 protected, padlockable in the OFF- position and with door interlock in the ON-position. The shaft can be adjusted to different installation depths.





| No. of poles | I_{in} (open) [A] | Rated operat. currents AC22A/ AC23A 400 V [A/A] | Type | Order number | Units/ type [pcs] | Weight/unit [Kg] |
|--------------|---------------------|---|----------------|--------------|-------------------|------------------|
| 3 | 315 | 315/315 | RVESD0315M03H3 | 1 | 3.34 | |
| 4 | 315 | 315/315 | RVESD0315M04H3 | 1 | 4.1 | |
| 3 | 315 | 315/315 | RVESD0315M12H3 | 1 | 3.34 | |
| 4 | 315 | 315/315 | RVESD0315M22H3 | 1 | 4.1 | |
| 3 | 400 | 400/400 | RVESD0400M03H3 | 1 | 3.34 | |
| 4 | 400 | 400/400 | RVESD0400M04H3 | 1 | 4.1 | |
| 3 | 400 | 400/400 | RVESD0400M12H3 | 1 | 3.34 | |
| 4 | 400 | 400/400 | RVESD0400M22H3 | 1 | 4.1 | |
| 3 | 500 | 500/500 | RVESD0500M03H3 | 1 | 3.34 | |
| 4 | 500 | 500/500 | RVESD0500M04H3 | 1 | 4.1 | |
| 3 | 500 | 500/500 | RVESD0500M12H3 | 1 | 3.34 | |
| 4 | 500 | 500/500 | RVESD0500M22H3 | 1 | 4.1 | |

Shafts and handles included as standard



| (mm) | P01 | P02 | P03 | P04 |
|------|-----|-----|-----|-----|
| A | 103 | 147 | 191 | 235 |
| A1 | 140 | 140 | 140 | 140 |
| A2 | 78 | 122 | 166 | 210 |
| B1 | 135 | 135 | 135 | 135 |
| B2 | 96 | 140 | 184 | 228 |
| C1 | 104 | 104 | 104 | 104 |
| C2 | 114 | 158 | 202 | 246 |

Placing options of the operating mechanism for RVSD500...800At the end of
the switch
03 or 04Between
the poles
12 or 22

| Technical data according to IEC 60947-3 | RATING | A | 500 | 630 | 800 | |
|---|--|--|--------------------------------|--|--|--|
| | | | Switch type | RVSD0500 | RVSD0630 | RVSD0800 |
| Rated insulation voltage and rated operational voltage AC-20, DC-20 | Pollution degree 3 | 50 Hz 1min. | V | 1000 | 1000 | 1000 |
| Dielectric strength | | | kv | 10 | 10 | 10 |
| Rated impulse voltage | | | kv | 12 | 12 | 12 |
| Rated thermal current and rated operational current AC-20, DC-20 in ambient 40°C ⁴⁾ with minimum cable cross section | Ambient 40°C Ambient 40°C Ambient 60°C | In open air In enclosure Cu | A A A mm ² | 500 500 500 2x150 | 630 630 630 2x185 | 800 800 800 2x240 |
| Rated operational current AC-21A | | ≤ 500V 690V 1000V | A | 500 500 500 | 630 630 630 | 800 800 800 |
| Rated operational current AC-22A | | ≤ 500V 690V 1000V | A | 500 500 500 | 630 630 630 | 800 800 800 |
| Rated operational current AC-23A | | ≤ 500V 690V 1000V | A | 500 500 200 | 630 630 400 | 800 800 400 |
| Rated operational current / poles in series, DC-21A ¹⁾ | 24...110 V 220 V 440 V 660 V | | A | 500/1 ²⁾ 500/2 ²⁾ 360/3 360/4 | 630/1 630/1 360/2 630/4 ²⁾ | 800/1 800/1 800/2 650/4 ²⁾ |
| Rated operational current / poles in series, DC-21B | 800 V 1000 V | | A | 500/5 500/6 | 400/5 400/6 | 600/5 600/6 |
| Rated operational power, AC-23 ³⁾ | 230 V 400 V 415 V 500 V 690 V | | KW | 165 275 287 287 500 | 200 355 355 400 630 | 250 450 450 560 800 |
| Rated breaking capacity in category AC-23 | | ≤ 500 V 690 V | A | 3200 3200 | 5040 5040 | 6400 6400 |
| Rated conditional short-circuit I_p (r.m.s.) and corresponding max. allowed cut-off current \dot{I}_c . | I_p (r.m.s.) Max. fuse size | 100 KA,500 V gG/aM | KA A | 61.5 500/450 | 90 800/1000 | 90 800/1000 |
| The cut-off current \dot{I} refers to values listed by fuse manufacturers (Single phase test acc.to IEC60269). | I_p (r.m.s.) Max. fuse size | 80 KA,690 V gG/aM | KA A | 59 500/500 | 83.5 800/1000 | 83.5 800/1000 |
| Rated short-time making withstand current | r.m.s I_{cw} | ≤1000 V 0.15s ≤1000 V 0.25s ≤1000 V 1s | KA KA KA | 38 36 20 | 38 36 20 | 38 36 20 |
| Rated short-time making capacity | Peak Value I_{cm} | ≤1000 V 1s | KA | 65 | 80 | 80 |
| Rated capacitor power when no initial charge on the capacitor | The capacitor rating are limited by the fuse link | 415 V 500 V 690 V | KVAr | 225 268 406 | 250 300 450 | 310 375 550 |
| Power loss / pole | With rated current | | W | 15 | 25 | 40 |
| Mechanical endurance | Divide by two oper. cycles | | Oper. | 10000 | 10000 | 10000 |
| Weight without accessories | 3-pole switch | | Kg | 6 | 6 | 6 |
| Terminal bolt size Terminal tightening torque Operating torque | Metric thread diameter x length Counter torque required 3-pole switch disconnector | mm Nm Nm | M12x40 50-75 27 | M12x40 50-75 27 | M12x40 50-75 27 | M12x40 50-75 27 |

1) Further rating on request

2) Category B

3) These values are given for guidance and may vary acc. to the motor manufacturer

4) Acc. to IEC 60947-1,\$ 6.1.1

Ordering information & Mounting dimension

Front operated switch-disconnectors RVSD500...800A


Switch-disconnectors, with pistol handle, base mounting, IEC

including a black ON-OFF plastic handle and shaft as standard. The handle is IP65 protected, padlockable in the OFF- position and with door interlock in the ON-position. The shaft can be adjusted to different installation depths.





| No. of poles | I_{th} (open) [A] | Rated operat. currents AC22A/AC23A 400 v [A/A] | Type | Order number | Units/ type [pcs] | Weight/unit [Kg] |
|--------------|---------------------|--|-----------|----------------|-------------------|------------------|
| 3 | 500 | 500/500 | RVSD50003 | RVESD0500M03H3 | 1 | 7 |
| 4 | 500 | 500/500 | RVSD50004 | RVESD0500M04H3 | 1 | 8.5 |
| 3 | 500 | 500/500 | RVSD50012 | RVESD0500M12H3 | 1 | 7 |
| 4 | 500 | 500/500 | RVSD50022 | RVESD0500M22H3 | 1 | 8.5 |
| 3 | 630 | 630/630 | RVSD63003 | RVESD0630M03H3 | 1 | 7 |
| 4 | 630 | 630/630 | RVSD63004 | RVESD0630M04H3 | 1 | 8.5 |
| 3 | 630 | 630/630 | RVSD63012 | RVESD0630M12H3 | 1 | 7 |
| 4 | 630 | 630/630 | RVSD63022 | RVESD0630M22H3 | 1 | 8.5 |
| 3 | 800 | 800/800 | RVSD80003 | RVESD0800M03H3 | 1 | 7 |
| 4 | 800 | 800/800 | RVSD80004 | RVESD0800M04H3 | 1 | 8.5 |
| 3 | 800 | 800/800 | RVSD80012 | RVESD0800M12H3 | 1 | 7 |
| 4 | 800 | 800/800 | RVSD80022 | RVESD0800M22H3 | 1 | 8.5 |

Shafts and handles included as standard



| (mm) | P01 | P02 | P03 | P04 |
|------|-----|-----|-----|-----|
| A | 136 | 201 | 266 | 331 |
| A1 | 112 | 177 | 242 | 307 |
| B1 | 130 | 195 | 260 | 325 |
| C1 | 148 | 213 | 278 | 343 |

Placing options of the operating mechanism for RVSD1000...1600At the end of
the switch
03 or 04Between
the poles
12 or 22

| Technical data according to IEC 60947-3 | | Pollution degree 3 | 50 Hz 1min. | RATING | A | 1000 | 1250 | 1600 |
|---|---|--------------------------|----------------------|--------------------------|--------------------------|--------------------------|--------------------------|-------------|
| | | | | Switch type | RVSD1000 | RVSD1250 | RVSD1600 | |
| Rated insulation voltage and rated operational voltage AC20, Dc20 | | | V | 1000 | 1000 | 1000 | 1000 | |
| Dielectric strength | | | kv | 10 | 10 | 10 | 10 | |
| Rated impulse voltage | | | kv | 12 | 12 | 12 | 12 | |
| Rated thermal current and rated operational current AC20/DC20 | Ambient 40°C | In open air | A | 1000 | 1250 | 1600 | | |
| with minimum conductor cross section | Ambient 40°C | In enclosure | A | 1000 | 1250 | 1600 | | |
| | Ambient 60°C | In enclosure | A | 1000 | 1250 | 1600 | | |
| | Cu | mm ² | 2x300 | 2x400 | 2x500 | | | |
| Rated operational current AC-21A | Up to 690 V | A | 1000 | 1250 | 1600 | | | |
| | 1000 V | A | 1000 | 1250 | 1600 | | | |
| Rated operational current AC-22A | Up to 415 V | A | 1000 | 1250 | 1600 | | | |
| | 500 - 690 V | A | 1000 | 1250 | 1600 | | | |
| Rated operational current AC-23A | Up to 500 V | A | 1000 | 1250 | 1250 | | | |
| | 690 V | A | 1000 | 1250 | 1250 | | | |
| Rated operational power, AC-23A (These values are given for guidance and may vary acc to the motor manufacturer) | 400...415 V | KW | 560 | 710 | 890 | | | |
| | 440 V | KW | 630 | 800 | 1000 | | | |
| | 500 V | KW | 710 | 900 | 1100 | | | |
| | 690 V | KW | 1000 | 1200 | 1600 | | | |
| Rated breaking capacity,AC-23A | Up to 500 V | A | 8000 | 10000 | 12800 | | | |
| | 690 V | A | 8000 | 10000 | 12800 | | | |
| Rated conditional short-circuit current I_p (r.m.s.) and corresponding max. allowed cut-off current \hat{I}_c . | I_p (r.m.s.) Max. fuse size | 80 KA ≤ 415 V | KA A | 100 1250/1250 | 100 1250/1250 | 100 1250/1250 | 100 1250/1250 | |
| The cut-off current \hat{I} refers to values listed by fuse manufacturers (Single phase test acc.to IEC60269). | I_p (r.m.s.) Max. fuse size | 100 KA ≤ 500 V | KA A | 106 1250/1250 | 106 1250/1250 | 106 1250/1250 | 106 1250/1250 | |
| Rated short-time withstand current | r.m.s I_{cw} | 690 V,0.25s 690 V, 1s | KA KA | 50 50 | 50 | 50 | 50 | |
| Rated short-time circuit making capacity | Max. distance from switch frame to nearest busbar/cable support | Peak Value I_{cm} | 690 V mm | 110 ⁴⁾ 150 | 110 ⁴⁾ 150 | 110 ⁴⁾ 150 | 110 ⁴⁾ 150 | |
| Rated capacitor power when no initial charge on the capacitor | The capacitor rating are limited by the fuse links | 415 V 500 V 690 V | KVAr KVAr KVAr | 460 550 750 | 575 690 950 | 730 880 1200 | | |
| Power loss / pole | At rated operational current | | | W | 19 | 29 | 48 | |
| Mechanical endurance | Divide by two for operation cycles | | Oper. | 6000 | 6000 | 6000 | | |
| Weight without accessories | 3-pole | | Kg | 14.5 | 14.5 | 16.5 | | |
| Terminal bolt size | Metric thread diameter x length | | mm | M12x50 | M12x50 | M12x60 | | |
| Terminal tightening torque | Counter torque required | | Nm | 50...75 | 50...75 | 50...75 | | |
| Operating torque | 3-pole switch disconnector | | Nm | 65 | 65 | 65 | | |

1) Acc. to IEC60947-1,\$ 6.1.1

Ordering information & Mounting dimension

Front operated switch-disconnectors RVSD1000...1600A


Switch-disconnectors, with pistol handle, base mounting, IEC

including a black ON-OFF plastic handle and shaft as standard. The handle and shaft as standard. The handle is IP65 protected, padlockable in the OFF- position and with door interlock in the ON-position. The shaft can be adjusted to different installation depths.





| No. of poles | I_{th} (open) [A] | Rated operat. currents AC22A/ AC23A 400 v [A/A] | Type | Order number | Units/ type [pcs] | Weight/ unit [Kg] |
|--------------------|---------------------------|---|------------|----------------|-------------------------|-------------------------|
| | | | | | | |
| 3 | 1000 | 1000/1000 | RVSD10003 | RVESD1000M03H3 | 1 | 15.5 |
| 4 | 1000 | 1000/1000 | RVSD10004 | RVESD1000M04H3 | 1 | 19 |
| 3 | 1000 | 1000/1000 | RVSD100012 | RVESD1000M12H3 | 1 | 15.5 |
| 4 | 1000 | 1000/1000 | RVSD100022 | RVESD1000M22H3 | 1 | 19 |
| 3 | 1250 | 1250/1250 | RVSD125003 | RVESD1250M03H3 | 1 | 15.5 |
| 4 | 1250 | 1250/1250 | RVSD125004 | RVESD1250M04H3 | 1 | 19 |
| 3 | 1250 | 1250/1250 | RVSD125012 | RVESD1250M12H3 | 1 | 15.5 |
| 4 | 1250 | 1250/1250 | RVSD125022 | RVESD1250M22H3 | 1 | 19 |
| 3 | 1600 | 1600/1600 | RVSD160003 | RVESD1600M03H3 | 1 | 18.6 |
| 4 | 1600 | 1600/1600 | RVSD160004 | RVESD1600M04H3 | 1 | 23.6 |
| 3 | 1600 | 1600/1600 | RVSD160012 | RVESD1600M12H3 | 1 | 18.6 |
| 4 | 1600 | 1600/1600 | RVSD160022 | RVESD1600M22H3 | 1 | 23.6 |

Shafts and handles included as standard




| (mm) | P01 | P02 | P03 | P04 |
|------|-----|-----|-----|-----|
| A | 175 | 255 | 335 | 415 |
| B | | 80 | 80 | 80 |
| A1 | 134 | 214 | 294 | 374 |
| B1 | 164 | 244 | 324 | 404 |
| C1 | 190 | 370 | 350 | 430 |

Placing options of the operating mechanism for RVSD2000...3200At the end of
the switch
03 or 04Between
the poles
12 or 22

| | RATING | A | 2000 | 2500 | 3200 |
|---|--|--|-----------------------------|-------------------------------|------------------------------------|
| Technical data according to IEC 60947-3 | Switch type | | RVSD2000 | RVSD2500 | RVSD3200 |
| Rated insulation voltage and rated operational voltage AC20, Dc20 Dielectric strength Rated impulse voltage | Pollution degree 3 50 Hz 1min. | V kv kv | 1000 10 12 | 1000 10 12 | 1000 10 8 |
| Rated thermal current and rated operational current AC20/DC20 with minimum conductor cross section | Ambient 40°C Ambient 40°C Ambient 60°C Cu | In open air In enclosure In enclosure mm ² | A A A 3x500 | 2000 2000 2000 4x500 | 2500 2500 2500 3x(100x10) |
| Rated operational current AC-21A | Up to 690 V 1000 V | A A | 2000 | 2500 | 3200 |
| Rated operational current AC-22A | Up to 415 V 500 - 690 V | A A | 2000 2000 | 2500 2500 | 3200 |
| Rated operational current AC-23A | Up to 500 V 690 V | A A | 1600 1600 | 2000 2000 | 2200 2200 |
| Rated operational power, AC-23A (These values are given for guidance and may vary acc to the motor manufacturer) | 400...415 V 440 V 500 V 690 V | KW KW KW KW | 887 1000 1125 1500 | 1109 1250 1406 1875 | 1420 1600 1800 2400 |
| Rated breaking capacity,AC-23A | Up to 500 V 690 V | A A | 1600 | 2000 | 2200 |
| Rated conditional short-circuit current I_p (r.m.s.) and corresponding max. allowed cut-off current I_c . | I_p (r.m.s.) | 80 KA | KA | 140 | 140 |
| The cut-off current I refers to values listed by fuse manufacturers (Single phase test acc.to IEC60269). | I_p (r.m.s.) | 100 KA | KA | 105 | 105 |
| Rated short-time withstand current | r.m.s- Value I_{cw} | 690 V,0.25s 690 V, 1s | KA KA | 80 50 | 80 55 |
| Rated short-time making capacity | Peak Value I_{cm} Max. distance from switch frame to nearest busbar/cable support | 690 V mm | KA 150 | 176 150 | 176 150 |
| Rated capacitor power when no initial charge on the capacitor | The capacitor rating are limited by the fuse links | 415 V 500 V 690 V | KVAr KVAr KVAr | 718 862 1187 | 898 1078 1484 |
| Power loss / pole | At rated operational current | | W | 37 | 58 |
| Mechanical endurance | Divide by two for operation cycles | | Oper. | 6000 | 6000 |
| Weight without accessories | 3-pole | | Kg | 32 | 32 |
| Terminal bolt size Terminal tightening torque Operating torque | Metric thread diameter x length Counter torque required 3-pole switch disconnector | mm Nm Nm | M12x60 50...75 65 | M12x60 50...75 65 | M12x60 50...75 65 |


Switch-disconnectors, with pistol handle, base mounting, IEC

including a black ON-OFF plastic handle and shaft as standard. The handle is IP65 protected, padlockable in the OFF-position and with door interlock in the ON-position. The shaft can be adjusted to different installation depths.




| No. of poles | I_{th} (open) [A] | Rated operat. currents AC22A/ AC23A 400 v [A/A] | Type | | Units/ type [pcs] | Weight/ unit [Kg] |
|--------------------|---------------------------|---|------------|----------------|-------------------------|-------------------------|
| | | | Type | Order number | | |
| 3 | 2000 | 1600 | RVSD20003 | RVESD2000M03H3 | 1 | 37 |
| 4 | 2000 | 1600 | RVSD20004 | RVESD2000M04H3 | 1 | 45 |
| 3 | 2000 | 1600 | RVSD200012 | RVESD2000M12H3 | 1 | 37 |
| 4 | 2000 | 1600 | RVSD200022 | RVESD2000M22H3 | 1 | 45 |
| 3 | 2500 | 2000 | RVSD25003 | RVESD2500M03H3 | 1 | 37 |
| 4 | 2500 | 2000 | RVSD25004 | RVESD2500M04H3 | 1 | 45 |
| 3 | 2500 | 2000 | RVSD250012 | RVESD2500M12H3 | 1 | 37 |
| 4 | 2500 | 2000 | RVSD250022 | RVESD2500M22H3 | 1 | 45 |
| 3 | 3200 | 2200 | RVSD32003 | RVESD3200M03H3 | 1 | 37 |
| 4 | 3200 | 2200 | RVSD32004 | RVESD3200M04H3 | 1 | 45 |
| 3 | 3200 | 2200 | RVSD320012 | RVESD3200M12H3 | 1 | 37 |
| 4 | 3200 | 2200 | RVSD320022 | RVESD3200M22H3 | 1 | 45 |


Shafts and handles included as standard



RVSD 20...RVSD125A



RVSD 125...RVSD3200A



Ordering Information

Accessories

| Handle with Soft | Length | Suitable for | Type | Order Number |
|---|--------|---------------------|-----------|----------------|
|  | 150mm* | RVSD20 .. RVSD125 | RVSDH125 | RVESD0125H03H3 |
|  | 260mm* | RVSD125...RVSD250 | RVSDH250 | RVESD0250H03H3 |
|  | 235mm* | RVSD315.. RVSD500 | RVSDH400 | RVESD0400H03H3 |
|  | 325mm* | RVSD500.. RVSD800 | RVSDH800 | RVESD0800H03H3 |
|  | 325mm* | RVSD1000.. RVSD3200 | RVSDH1600 | RVESD1600H03H3 |

Auxiliary Block




RVSA10 NO
RVSA01 NC

Type Function
Suitable for RVSD20...
RVSD3200A

RVESD0A10H03H3
RVESD0A01H03H3

* Different Shafts length are available

Notes



www.roveelectricindia.com

ROVE Electric Pvt Ltd.

SF No: 193/1B, Uzhaippalar Street,
Udayampalayam Road, Vellakinar Village,
Coimbatore - 641029. Tamil Nadu. INDIA.
Email: sales@rovelectric.co.in

Electricity is the most indispensable source of energy in this modern era. ABN Electric excel in the specialized manufacturing, servicing and exporting of low voltage Switchgear, controlgear, Power Busbars & Diesel Gensets. since its establishment, the company is a fully self contingent, where every component is formulated, developed, processed and manufactured to latest requirements.

"We Make Ideas Work"

ABN electric hold an excellent technical infrastructure and highly skilled team of professionals. The R&D wing constantly work on innovations and determine to transform conventional products to new generation products.

"Conviction"

Our products are accredited with Global Standards which stand as a testimony to our strict and vigilant quality control. We are committed to quality and innovation besides prompt after sales service.